

## ***INSTALLATION INSTRUCTIONS FOR RECESSED DISPLAY CASES***

Place shims around box of case to square and level supporting box bottom, front and rear.

Drill holes in door channel perimeter and drive flat headed screws in channel all around frame to attach box to rough opening.

If needed, standards can be removed and screws used to attach back of case in opening. Then replace standards to cover the screw heads.