



ASSEMBLY INSTRUCTION


Remove all items from the carton . Verify all pieces before assembly.


PART LIST


KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION
1	5	Caster	6	1	Seat	11	1	Backrest Bolt + Washers
2	1	Base	7	1	Backrest	12	1	M6 Size Allen Wrench
3	1	Seat Post	8	1	Backrest Post	13	2	Armrest
4	1	Seat Post Cover	9	2	Backrest Screw			Arm Width Adjustment Knob + Washers
5	1	Mechanism	10	1	M5 Size Allen Wrench	14	2	














- B Back Angle Adjustment Lever
- C Combination Seat / Back Angle Adjustment Lever with Infinite Lock
- D Seat Height Adjustment Lever
- E Tension Adjustment Knob
- F Forward Tilt Lever

PREVENTIVE MAINTENANCE AND WARNING!

- USE THIS PRODUCT ONLY FOR SEATING ONE PERSON AT A TIME.
- DO NOT USE THIS CHAIR AS A STEP STOOL / LADDER.
- DO NOT SIT ON ANY PART OF THE CHAIR EXCEPT THE SEAT.
- DO NOT USE CHAIR ON UNEVEN FLOOR SURFACES.
- DO NOT USE CHAIR UNLESS ALL BOLTS , SCREWS AND KNOBS ARE TIGHT . AT LEAST EVERY
- SIX MONTHS, CHECK ALL BOLTS, SCREWS AND KNOBS ARE TIGHT. AT LEAST EVERT SIX MONTHS, CHECK ALL BOLTS, SCREWS AND KNOBS TO BE SURE THEY ARE TIGHT. IF ANY PARTS ARE MISSING, BROKEN, DAMAGED OR WORN, STOP USE OF THE PRODUCT UNTIL REPAIRS ARE MADE USING FACTORY AUTHORIZED PARTS.

 DISPOSE OF PACKAGING PROPERLY. PLASTIC BAG IS NOT A TOY. DO NOT USE PLASTIC BAG AS HEAD COVERING IT MAY CAUSE SUFFOCATION.

- FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.

49802A / LM59802A