

















**Please unscrew all hardware from cushion before assembly.**  
**Por favor de destornillar todos los tornillos del cojín antes de ensamblar la silla.**

MODEL: 16205 16206 16207 16215 16216 16217

(1)x1  BACK	(2)x1  SEAT	(3)x1  TU009-EXT	(4)X1(L)X1(R)  16206 / 16207 Arms
(5)x1  Gas Lift	(6)x1  Base	(7)x1  TU009	(8)X1  Mechanism
(9)X5  Casters	<p>Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.</p>		
<p>MODEL: B16206</p> <p>Ax4  M8X22 Mechanism Screws</p> <p>Bx4  M6X22 Back Bar Screws</p> <p>Cx6  M6X22 Arm Screws</p>		<p>MODEL: B16207</p> <p>Ax4  M8X22 Mechanism Screws</p> <p>Bx4  M6X22 Back Bar Screws</p> <p>Cx6  M6X30 Arm Screws</p>	



16215 16205

16216 16206

16217 16207